

Manual Override Procedure

1. Locate the included flexible shaft in your owner's packet



2. For compact assembly motor 225007 or the 225008, attach a #3 square bit on the end of the motor.
 - a. For all other motors, attach flexible shaft to the 1/4" hex fitting on the end of the motor



3. For compact assembly motor 225007 or the 225008, attach 1/4" socket & ratchet, or drill to the other end and turn in the proper direction to move the room.
 - a. For all other motors, attach 1/4" socket & ratchet, or drill to the other end and turn in the proper direction to move the room.
4. If the cables tighten, and the motor is difficult to turn, **REVERSE THE DIRECTION**.
 - a. Over-torquing can happen, resulting in severe damage to the system.

Note: If using compact assembly motor 225007 or the 225008, if the drive shaft or motor has failed, the manual override can plug directly into the gearbox.