

CABLE SLIDE JAMB INSTALLATION	BRAND: ACCU SLIDE	CREATED DATE: 07/8/2024
ID NUMBER: SQS.ACU.004e	TYPE: G4 [ECONO]	REVISION:

Step 1: Mount Top Jamb Bracket	<p>Fasten the upper section of the jamb to the inside of the rough opening.</p> <p>Use #10 or #14 flat or pan head [lag screws in lumber core aluminum tube and stick built rough openings] in each pre-punched hole.</p>	<p style="color: red; font-size: small;">FASTEN TOP BRACKET THROUGH THE INSIDE OF THE ROUGH OPENING.</p> <p style="color: blue; font-size: small;">Do not fasten bottom bracket</p> <p style="color: blue; font-size: small;">G4 Jamb</p> <p style="color: blue; font-size: small;">Break Away Point</p>
---	---	--

Step 2: Mount Bottom Jamb Brackets	<p>Cut the zip ties off the cables.</p> <p>A. Pull the lower portion of the jamb bracket up to detach it from the top portion of the jamb.</p> <p>B. Lower the bottom of the jamb straight down to the inside bottom of the rough opening.</p> <p>C. Add fasteners to the top and bottom tabs on the</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 30%;"> <p style="font-size: x-small;">A. DETACH LOWER JAMB BRACKET</p> <p style="color: red; font-size: small;">PULL BOTTOM HALF UP TO DETACH</p> </div> <div style="width: 30%;"> <p style="font-size: x-small;">B. FASTEN LOWER JAMB BRACKET THROUGH INSIDE OF ROUGH OPENING</p> </div> <div style="width: 30%;"> <p style="font-size: x-small;">C. FASTEN TOP AND BOTTOM THROUGH INTERIOR WALL</p> </div> </div>
---	--	---

Step 3: Mount Corner Pulley Brackets	<ol style="list-style-type: none"> Align the screw of the lower pulley strap with the edge of the rough opening. The bottom of the corner pulley brackets should be placed 1" to 1-1/4" away from the rough opening. <p>Fasteners: #10 to #14 flat or oval head screws.</p>	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p style="font-size: x-small;">CORNER PULLEY BRACKET</p> </div> <div style="text-align: center;"> <p style="font-size: x-small;">CORNER PULLEY BRACKET</p> <p style="color: red; font-size: x-small;">1" - 1-1/4"</p> </div> </div> <div style="text-align: center; margin-top: 10px;"> <p style="font-size: x-small;">ROUGH OPENING</p> </div>
---	--	---