


CABLE SLIDE JAMB INSTALLATION	BRAND: BAL ACCU SLIDE	CREATED DATE: 06/30/2024
ID NUMBER: SQS.ACCU.004h	TYPE: HYBRID	REVISION:

<p>Step 1:</p>	<p>Set Jamb in Rough Opening</p>	<ol style="list-style-type: none"> The Hybrid Slide Jamb should be seated tight against the rough opening. Install right and left hand jamps to the upper portion of the rough opening through the exterior bulb seal track. [When Applicable] Fasten upper and lower anchor tabs in each hole. <p>Fasteners: #8 or #10 flat or pan head fasteners in each pre-punched hole.</p>	
<p>Step 2:</p>	<p>Install Interior Jamb Clamp</p>	<p>Seat the beveled edge of the Jamb Clamp into the channel of the jamb on the interior of the RV from top to bottom.</p> <p>The Clamp is a structural component.</p> <p></p> <p>Fasteners: #8 or #10 pan head screws in each pre-punched hole.</p>	
<p>Step 3:</p>	<p>Mount Corner Pulley Brackets</p>	<ol style="list-style-type: none"> Align the screw of the lower pulley strap with the jamb clamp channel. The bottom of the corner pulley brackets should be placed 1" to 1-1/4" away from the rough opening. <p>Fasteners: #10 to #14 flat or oval head screws.</p>	
<p>Step 4:</p>	<p>Cross Measure Between Jamb</p>	<p>Cross measure the distance between the jamps to ensure that they are square.</p> <p>Tolerance: 1/4" [+/-]</p>	