

<b>CABLE SLIDE OPENING PREP</b>	<b>BRAND:</b> BAL EXACT SLIDE G5.5	<b>CREATED DATE:</b> 06/14/2024
<b>ID NUMBER:</b> SQS.EXT.001	<b>TYPE:</b> Exact Slide	<b>Revision:</b>

<p><b>Step 1:</b></p>	<p><b>Clean Rough Opening</b></p>	<ol style="list-style-type: none"> <li>1. Remove all burrs, glass overhang or metal overhang.</li> <li>2. Overhang of material will prohibit the jambs from seating against the rough opening.</li> </ol>	
<p><b>Step 2:</b></p>	<p><b>Cross Measure Rough Opening</b></p>	<ol style="list-style-type: none"> <li>2. Cross measure the rough opening.</li> </ol> <p><b>Tolerance:</b> 1/4 [+/-]</p>	
<p><b>Step 3:</b></p>	<p><b>Install Sill Material</b></p>	<ol style="list-style-type: none"> <li>3. Install drip cups or aqua-diverters into the bottom corners of the rough opening [when applicable]</li> <li>4. The sill material should extend to the edge of the rough opening.</li> </ol>	