

CABLE SLIDE JAMB INSTALLATION	BRAND: BAL EXACT SLIDE G5.5	CREATED DATE: 06/30/2024
ID NUMBER: SQS.EXT.004	TYPE: EXACT SLIDE	REVISION:

Step 1:	Set Jamb in Rough Opening	<ol style="list-style-type: none"> The Exact Slide Jamb should be seated tight against the rough opening. Install right and left hand jams to the upper portion of the rough opening through the exterior bulb seal track. [When Applicable] Fasten upper and lower anchor tabs in each hole. <p>Fasteners: #8 or #10 flat or pan head fasteners in each pre-punched hole.</p>	
Step 2:	Install Interior Jamb Clamp	<p>Seat the beveled edge of the Jamb Clamp into the channel of the jamb on the interior of the RV from top to bottom.</p> <p> The Clamp is a structural component.</p> <p>Fasteners: #8 or #10 pan head screws in each pre-punched hole.</p>	
Step 3:	Cross Measure Between Jamb	<p>Cross measure the distance between the jams to ensure that they are square.</p> <p>Tolerance: 1/4" [+/-]</p>	