

<b>CABLE SLIDE CABLE ATTACHMENT</b>	<b>BRAND:</b> BAL EXACT SLIDE G5.5	<b>CREATED DATE:</b> 07/29/2024
<b>ID NUMBER:</b> SQS.EXT.006	<b>TYPE:</b> Exact Slide G5.5	<b>REVISION:</b>



**Do not tighten the coupler nuts or jamb nuts on the interior standoff brackets.**

Tightening the top interior cables first, traps slack in the chain and will cause operation issues for the consumer.

<b>Step 1:</b>	<b>Attach Exterior cables</b>	<ol style="list-style-type: none"> <li>1. Attach the exterior cables to each standoff bracket.</li> <li>2. Place a rubber grommet into the slotted hole of the standoff.</li> </ol>	
<b>Step 2:</b>	<b>Attach Top Interior Cables</b>	<ol style="list-style-type: none"> <li>3. Attach interior top cable through the top of the interior standoff bracket and the plastic cable guide, then through the bottom hole in the bracket.</li> </ol> <p>⚠ Do not tighten the top interior cables with the coupler nut. This is the last step in the tensioning process.</p>	<p>TOP INTERIOR</p> <p><b>DO NOT TIGHTEN TOP INTERIOR CABLES</b></p>
<b>Step 3:</b>	<b>Attach Bottom Interior Cables</b>	<ol style="list-style-type: none"> <li>1. Attach interior bottom cable through the bottom of the interior standoff bracket and the plastic cable guide, then through the top hole in the bracket.</li> </ol> <p>⚠ Install the washer and coupler nut.</p> <p>⚠ Do not install the jamb nut unit the tensioning process has been completed.</p>	<p><b>DO NOT ADD JAMB NUT UNTIL THE TENSIONING PROCESS IS COMPLETE</b></p>