

## Lubrication Instructions



1. Fully extend the slide-out room.
2. Wipe the TOP of the slide-out arms free of any dirt or debris.
3. Apply the lube directly to the top of the slide-out arms. We recommend using a wax based, self-cleaning, lubrication, such as [DuPont Chain-Saver Wax-Based Chain lube](#).
4. Cycle the room one complete time while spraying the lubrication on/into the top nylon wear block as needed. (Photos on pages 2 & 3).
5. Complete step #4 as needed until the slide-out is operating smooth and quietly. In certain circumstances 24-hour dry time may be required to eliminate excessive noise and/or vibration.

