





DEPTH OF THE ROOM

⇒ THE DISTANCE BETWEEN THE INTERIOR STANDOFF BRACKET AND THE EXTERIOR STANDOFF BRACKET IS CONSIDERED THE TRAVEL DEPTH OF THE ROOM.

⇒ THE STANDOFF BRACKETS REPRESENT THE STOPPING POINT WHEN EXTENDING AND RETRACTING.

⇒ THIS MEASUREMENT IS KEY WHEN DESIGNING THE CORRECT CABLE LENGTH.



MEASURE THE INTERIOR STANDOFF BRACKET TO THE EXTERIOR STANDOFF BRACKET TO CONFIRM THE DEPTH.

IF THE BRACKETS ARE MOUNTED TO FAR FROM THE EDGE OF THE END WALL ON THE SLIDE, THE CABLES CAN BE TOO LONG TO ADJUST PROPERLY.

SOME DESIGNS ARE REQUESTED WITH A SHORTER TRAVEL DEPTH, TO CREATE A DIFFERENT STOPPING POINT WHEN EXTENDING THE ROOM.

ALL STANDOFF BRACKETS SHOULD BE INSTALLED IN THE SAME ORIENTATION AND BE VERTICALLY ALIGNED