







CABLE SLIDE CABLE ADJUSTMENT	BRAND: BAL EXACT SLIDE G5.5	CREATED DATE: 06/28/2024
ID NUMBER: SQS.EXT.007	TYPE: Exact Slide	REVISION:

Prepare	 <p>Tools:</p> <ul style="list-style-type: none"> ⇒ 3/8" Gear Wrench ⇒ 7/16" Gear Wrench ⇒ Needle-nose Pliers ⇒ [Opt] Tension Gauge <p>1. RETRACT THE ROOM COMPLETELY</p> <p>⚠ Leave the washer, coupler nut and jamb nut off the top interior cables or loosely attach them.</p>	<p>RETRACT THE ROOM</p>  <p>KEEP INTERIOR TOP CABLES LOOSE</p>
	<p>Step 1: Bottom Cables</p> <ul style="list-style-type: none"> 2. Attach needle-nose vice grips to the barrel of the threaded cable end. 3. Tension the bottom interior cables to 1/4" deflection using the coupler nut on the threaded end of the cable or 20 lbs. 4. Fully Extend and Retract the Room Three [3] times. 	 <p>IN</p> <p>↑</p> <p>↓</p> <p>OUT</p> <p>X 3</p>
<p>Step 2: Cycle the Room x 3</p> <ul style="list-style-type: none"> 5. After cycling the room 3 times, retract the slide and check the bottom cable tension. Continue to tension the bottom interior cable to 1/4" deflection or 20 lbs. 6. Add and tighten 1/4" jamb nut to lock the tension in place. 	<p>Bottom Cable Tension</p> <p>1/4" up ↑ or 1/4" down ↓</p>  <p>20 lbs.</p> <p>⚠ You should not be able to turn the jamb nut with your fingers.</p> <p>STACK UP EXAMPLE</p> 	
<p>Step 3: Top Interior Cables</p> <ul style="list-style-type: none"> 7. Attach needle-nose vice grips to the barrel of the threaded cable end. 8. Tension the top interior cables to 1/2" deflection using the coupler nut on the threaded end of the cable or 10 lbs. 9. Add and tighten 1/4" jamb nut to lock the tension in place. 	<p>Top Cable Tension</p> <p>1/2" up ↑ or 1/2" down ↓</p>  <p>10 lbs.</p> <p>⚠ You should not be able to turn the jamb nut with your fingers.</p> <p>STACK UP EXAMPLE</p> 